


*Bedienungsanleitung · Instruction Manual · Mode d'emploi  
Manual de Instrucciones · Istruzioni per l'uso · Gebruiksaanwijzing  
Bruksanvisning · Käyttöohje*




# KODAK CAROUSEL S-AV 2050/ S-AV 2050 AF Projector



PROFESSIONAL PHOTOGRAPHIC DIVISION PRESENTATION TECHNOLOGIES


**Kurzanleitung**  
**Summary**  
**Mode d'emploi résumé**

**1.**




**Esquema resumido**  
**Introduzione**  
**Aanwijzingen in 't kort**

**2.**




**Igångsättning**  
**Johdanto**


**3.**




**4.**




**5.**




**6.**





**7.**



**8.**





# Switching-on the projector

## Projector features

- 1 Focusing knob for rack focusing lens
- 2 Slide gate
- 3 Slide tray lock
- 4 Forward slide-change and select button
- 5 Reverse slide-change button
- 6 12-pole socket
- 7 Autofocus on-off switch
- 8 Switch for external or internal lamp control
- 9 Height adjustment knob
- 10 Locking device for height adjuster
- 11 Retractable handle
- 12 Lamphouse door
- 13 Holder for additional spare lamp
- 14 Standard condenser lens  
(in position for 24 mm × 36 mm slides)
- 15 Heat filter
- 16 Lampholder latch
- 17 Lamp changeover lever
- 18 Lamp adjustment (horizontal)
- 19 Lamp socket with 2 lamps
- 20 Mirror adjustment (vertical)
- 21 Rapid lamp change lever
- 22 Mains switch
- 23 Fuse holder
- 24 Mains socket
- 25 Fan vent
- 26 Zero position indicator
- 27 6-pole socket

## Using the instruction manual

Open out the front and rear cover flaps. These diagrams apply to the following text.

The principal stages of operating the projector are illustrated on the front flap in illustrations 1–8.

### Voltage selector (Figure P)

The voltage selector on the underside of the projector is set at manufacture to 220/230 V. Before altering the voltage selector, disconnect the mains supply and fit the correct fuse.

### Mains fuse (Figure Q)

220/230 V or 240/250 V: 1.6 A slow blow fuse (already installed).  
110/120 V or 130 V: 3.15 A slow blow fuse (packed separately).


The fuse must only be changed after the mains supply has been disconnected. Pull out the fuse holder (23) by pressure on the small catch. Remove the fuse and insert the new one.

The projector is supplied with a fuse or 220/250 V fitted.

### Setting-up the projector

Place the projector on a firm, vibration-free base. The projector may be set at an angle of up to 30° from the horizontal in any direction. Check that the projector can draw in sufficient cold air for cooling and that warm air can be freely expelled. (The projector requires 20 litres of cooling air per second.) Keep air vents on the underside, at the rear of the projector, and on the lamphouse door, free from obstructions.

Note:  
For fastening the projector in a fixed projection position, fixing holes suitable for self-tapping screws can be found in the back of the projector and in the base-plate (Figure).



## Slide mounts

The projector accepts all slides of 5 cm  $\times$  5 cm external size and up to 3.2 mm thick (complying with DIN 108). For a slide presentation it is important to use glass mounted slides throughout to avoid the need for refocusing.

Damaged, distorted or warped slides should not be used as they may disrupt the transport mechanism.

## Fitting the slide tray (Figures R & S)

- Turn that transparent cover on the slide tray counter-clockwise and lift it off.
- Insert the slides into the tray.
- Replace the cover and lock it.
- Check that the baseplate of the slide tray is locked in position (Figure R). (When locked, the baseplate cannot be rotated.)
- Place the tray in its approximate position on the projector and rotate it until it locks in the zero position (Figure S).

## Lenses

The KODAK RETINAR S-AV 1000 range of lenses, the high-precision KODAK RETINAR S-AV 2000 lenses and rack focusing lenses can be used.

For technical data on KODAK RETINAR S-AV 1000 and S-AV 2000 lenses see page 56.

The table of projected picture sizes (page 59) may help you to select the optimum lens focal length for each projection condition.

## Key to table:

Scale a = Projection distance in metres

Scale c = Projected picture width in metres

Scale b<sub>1</sub> = Picture width of slide  
24  $\times$  36 mm horizontal format

Scale b<sub>2</sub> = Picture width of slide  
24  $\times$  36 mm vertical format

Scale b<sub>3</sub> = Picture width of slide  
40  $\times$  40 mm

Example: A projection distance of 10 m with 24  $\times$  36 mm format (scale b<sub>1</sub>) and a 150 mm lens produces a picture width of 2.30 m.

## Condenser settings

(see summary on the front cover flap, Figure 4).

As supplied, the projector is fitted with the standard condenser lens (drawn in black in the diagram) in position for 24  $\times$  36 mm slides.

For 40 mm  $\times$  40 mm slides, the standard condenser lens is put into the adjacent right-hand slot.

When using the 200 mm and 253 mm lenses, the standard condenser lens should be replaced by the special condenser lens supplied with these lenses. The special condenser lens is also recommended when projecting 40 mm  $\times$  40 mm slides with the RETINAR 135 mm, 150 mm and 180 mm lenses, giving better overall illumination.

Note: Ensure that the curved side of the standard condenser lens or special condenser lens is always facing the lamp.

## Setting the lamp control

The position of the lamp control switch (8) depends on the application.

**INT:** Position for single projector mode. Lamp switching is controlled inside the projector.

**EXT:** Position for dissolve and multiple projector modes. The lamp only comes on when an external control unit is connected via the 12-pole socket (7).

## Mains connection


Connect the projector to the mains with the 3.5 m mains lead supplied. Turn on the mains switch (22), the projection lamp comes on and the fan operates.

## Centering the lamp (Figure T)

The projection lamp is adjusted at manufacture. **Only the correctly adjusted lamp yields maximum of brightness and gives optimum of durability.** Check the adjustment again before using the projector: it may have changed in transit.

- After switching off the projector, look through the lens and check the position of the lamp filament.
- 135 mm and longer focal length lenses: Place the pinhole slide enclosed with these lenses in the slide gate. Switch on the projector, fit the lens cap over the lens and observe the lamp filament images projected on the lens cap. Centre the lamp as shown below.

To be correctly adjusted the filaments must be in line and should not overlap (right-hand diagram).



The left-hand diagrams show incorrect adjustments. To correct, proceed as follows:

- Open the lamphouse door (12).
- Turn the adjustment screw (18) for horizontal adjustment.
- Move the adjustment stud (20) up or down for vertical adjustment.

## Levelling the projector (Figure U)

The height of the projector is adjusted by rotating the two knurled knobs (9), on the sides of the projector. They can then be locked in position by turning the inner knobs (10).

# Operation

## Focusing the image (Figure U)

Press the slide advance button (4): The first slide will transport into the slide gate and be projected.

Focus the projected image either by turning the lens or by turning the milled wheel (1) when using rack focusing lenses.

## Autofocus (S-AV 2050 AF only)

The projector has an autofocus device which avoids the need to refocus manually. The infra-red focusing begins during the dark period. In dissolve mode, the operation of the autofocus is not visible on screen. With the over-ride feature it is still possible to have individual focusing by remote control – the autofocus is re-activated after the next slide change.

Before a show, the first slide must be focused manually. First switch on the autofocus (7) and then focus the image on the screen as described in "Focusing the image".

**Note:** In order to avoid large autofocus shifts during a slide presentation, it is recommended not to mix glass and glassless mounts in one show. For two or more projector dissolve shows use glass mounted slides only and switch off autofocus.

## Slide-changing

### 1. Using the buttons on the Projector

- Forward slide change:  
Press button (4) .
- Reverse slide change:  
Press button (5) .
- Individual selection:  
Press button (4)  and hold it down.  
The slide tray can now be turned by hand to any position. Note that after releasing the button the slide tray moves forward one position.

### 2. Using the KODAK CAROUSEL Remote Control

For single projector operation, connect the plug on the remote control cable to the 6-pole socket (27) on the projector. In dissolve mode the cable is plugged into the appropriate socket on the dissolve unit.

The remote control operates the following functions:

- Slide change forward. 
- Slide change reverse. 

Focusing.  
KODAK extension cables can extend the remote control cable up to 24 m.

### 3. With the KODAK Interval Timer

The KODAK Interval Timer is available for automatic slide changing at preset intervals. It can be set from about 4 to 40 seconds. In single projector mode it plugs into the 6-pole socket (27) on the projector.

### 4. With the KODAK S-AV Infrared Remote Control, Model TF, type II

This consists of a hand-held battery powered transmitter and a receiver. Forward and backward slide transport and focus can be controlled without cables up to a distance of about 30 metres from the receiver. The receiver can be attached to the projector (holder is supplied) and is plugged into the 6-pin socket (27).

## Changing the slide tray (Fig. V)

Always lift off the slide tray in the zero position. By pressing button (4) the slide tray can be turned by hand to the zero position.

The zero position indicator (26) lights up when the slide tray is in the zero position, or has been lifted off.

In an emergency, e.g. transport failure, the tray can be removed from the projector in any position. To do this, push aside and hold the slide tray centering latch (3) while lifting off the slide tray. Remove the slide from the slide gate.

Having removed the slide tray, turn it over and rotate the base plate until it locks in position. Otherwise the slide tray cannot be replaced on the projector.

## Rapid lamp changer (Figure W)

With the rapid lamp changer (21), the spare lamp ( $L_2$ ) can be brought into use immediately if the normal lamp ( $L_1$ ) fails.

- Push the rapid lamp changer (21) to the right to position 2 . The spare lamp is now ready to be used.

The spare lamp ( $L_2$ ) may not be perfectly centered, but illumination evenness should be adequate for completion of a show. After the slide show insert a new lamp ( $L_1$ ) and center it.

# Other projection modes

## Replacing a defective lamp (Figures X and Y)

Unplug the mains lead before replacing a defective lamp! Let the projector cool before you touch the lamp and the part around it!

- Open the lamphouse door (12).
- Push the rapid lamp changer (21) to the right until it stops .
- Swing out the lamp changeover lever (17) until the lampholder latches into position.
- Remove the defective lamp. Always handle lamps by the protective sleeve when inserting to avoid getting fingerprints on the glass. When the lamp is in place, remove the sleeve.
- Push up the lampholder latch (16) and swing back the lever (17).
- Push the rapid lamp changer (21) fully to the left into the operating position .
- Centre the operating lamp (L<sub>1</sub>).

A further spare lamp can be accommodated in a holder (13) on the inside of the lamphouse door.

## Continuous projection with 81 slides

Before putting on the full slide tray, insert an additional 81st slide in the slide gate.

For automatic slide changing, plug the KODAK Interval Timer into the projector's 6-pole socket (27).

## Dissolve and multi-projection mode

For dissolve and multi-projection mode, the projector can be connected to external control units via the 12-pole socket (6) (see Technical data).

**Note: Always use the original KODAK accessory!**

- Press switch (8) to **EXT**. In this setting, the lamp is controlled by an external control unit.

The KODAK range of accessories includes control units for dissolve and multi-projection modes:

- The KODAK S-AV Programmable Dissolve Control is a microprocessor controlled digital dissolve unit for two projectors with 12-pole standard socket. It can make AV programmes with a wide range of visual effects. The keyboard provides five dissolve rates, as well as several special effects.

An outstanding feature of the unit is its built-in protection against loss of sound and slide synchronization.

The dissolve control can form part of more complex multivision installations. The auxiliary connector permits other control functions to be programmed: e.g. a third projector, tape stop and restart, film projector, strobe, or room lights.

- The KODAK CAROUSEL S-AV Dissolve Control Model B can be used in impulse mode, frequency-modulation mode or in digital mode. The control pulses can be transferred direct onto a tape recorder.

## Zero-position indicator

To enable the operator to recognize immediately when all projectors in a multi-projector presentation are zeroed, the projector is fitted with a zero-position-indicator (LED) (26) which lights when the slide tray is zeroed.

## Snap facility (Figure A)

The snap facility is an electromagnetically controlled shutter, built into the projector, which can be controlled via the projector's 12-pole socket. The light path from the projection lamp can be suddenly cut off and then restored, making numerous visual effects possible (see Technical Data).

## Slide change times

The KODAK CAROUSEL S-AV 2050, 2050 AF and 2054 Projectors have a slide-change time of one second instead of 1.5 seconds with earlier S-AV projectors.

For this reason, slide presentations which are programmed with a slide-change time faster than 1.5 seconds cannot be projected efficiently on KODAK CAROUSEL S-AV 2000, 2020 and 2030 Projectors. However, slide presentations which were programmed with these projectors can be run on the faster models without difficulty.

# Servicing

# Accessories

## Tape Control of a Single Projector (Figure Z)

In single projector slide-tape presentations, the slide change is simply controlled by the tape recorder. The recorder must be fitted with an AV head with a built-in slide control unit or have an external slide control unit connected. (Control pulse duration: 0.2 to 0.75 seconds with 50 Hz; 0.18 to 0.6 seconds with 60 Hz.)

The connection to the projector is made via the 6-pole socket (27).

The KODAK CAROUSEL Twin Socket Model B together with the KODAK Remote Control Cable, permits remote focusing during tape recorder control.

## Projection in parallel

With parallel projection, the projectors linked in parallel are simultaneously operated, either by remote control, interval timer or slide control unit. To do this, a connection cable to the twin socket and a KODAK CAROUSEL Twin Socket, Model B are required for each additional projector.

## Maintenance

Dirt and dust can have adverse effects on the lubricants used in the projector and thus cause malfunctions. Therefore the projector and the slide tray should be returned to the KODAK Customer Service Department after approximately 1500 hours of operation.

Where the projector is used in very dusty locations (e.g. exhibitions) more frequent servicing may be advisable.

Cleaning of the projector optics, such as the lens, condenser and heat filter should be carried out using a soft lint-free cloth or camel hair brush.

The heat filter fits loosely into its holder to allow room for expansion as it gets warm. Take care not to bend the holder during cleaning.

## Possible problems during operation

- Lamp fails to light, but the fan operates:
  - Switch for lamp control (8) in wrong position.
  - Defective lamp.
- Projected image insufficiently illuminated:
  - Condenser lens in wrong position.
  - Wrong condenser lens fitted.
  - Lamp not centered.
  - Lamp changeover lever not exactly in position 1 or 2.
- Switching on the projector, the lamp fails to light and the fan does not operate:
  - Fuse blown.
  - Thermal overload cut-out has switched the projector off.
- Slide transport problem:
  - Slide damaged.
  - Magazine base plate not located in zero position.
  - Magazine base plate bent.
  - Remote control cable exceeds the permitted 24 m extension.
  - Slide transport pulse too short.

- KODAK RETINAR S-AV 1000 range of lenses and high-precision KODAK RETINAR S-AV 2000 lenses in various focal lengths (see page 56; 57 figure N and O).
- KODAK CAROUSEL S-AV 2000 Slide Tray with transparent cover. The slide trays hold up to 80 slides (Figure K).
- KODAK CAROUSEL Remote Control (4 m) (Figure F), plus Extension Cables 4 m and 16 m.
- KODAK S-AV Infrared Remote Control, Model TF, type II, for lead-less remote control of the projector up to about 30 metres (Figure G).
- KODAK CAROUSEL Interval Timer, adjustable from approximately 4 to 40 seconds (Figure H).
- KODAK CAROUSEL Twin Socket, Model B for simultaneous connection of a Remote Control and a slide synchronizer. Also used for parallel connection of projectors (Figure I).
- KODAK S-AV Cassette Recorder 200, mono audio recorder with built-in AV control track facility; capable of controlling slide changes on one or two projectors independently. With single projector control, automatic tape stops can be programmed. Control signals from external dissolve units can also be recorded (Figure L).
- KODAK S-AV Programmable Dissolve Control for two projector tape-slide presentations with a wide range of effects (Figure M).
- KODAK CAROUSEL Carrying Case (Figure J).

# Technical data

Gravity feed slide change with pressure levers in two planes to ensure good slide alignment.

Slide format up to 40 mm × 40 mm. Maximum slide thickness 3.2 mm (DIN 108).

Universal lens mount for KODAK RETINAR Lenses and lenses with rack focus.

Slide change time: 1 second with 50 Hz operation; 0.9 seconds with 60 Hz operation.

Height setting to a maximum of 6° via two locking, adjusting knobs.

The projector will also function on a slope of up to 30° in any direction.

## Illumination

Two 24 V/250 W halogen lamps (G6.35-EHJ, Cat. 709 2539) fitted on a rapid lamp changer (operational lamp and spare lamp).

300 hours of average lamp life. For replacement lamp can be swung out.

Lamp control switch, internal or external depending on projection mode.

Effective light intensity of approximately 950 lumens with 24 mm × 36 mm slides and with KODAK RETINAR 93 mm lens.

Interchangeable condenser system for slide formats 24 mm × 36 mm and 40 mm × 40 mm, and for lenses with longer focal lengths.

## Operation range (Figure B)

The permissible operating range of the projector depends on the ambient temperature and the mains voltage.

a = Ambient temperature (°C)

b = Mains voltage

c = Nominal voltage

d = 15% Undervoltage

e = 10% Overvoltage

f = Lamp voltage

Should the projector overheat, e.g. due to lack of cooling air or jamming of the slide transport mechanism, the built-in thermal cut-out automatically switches off the projector and then switches it on again, once it has cooled down.

## Electrical system

Voltage selector for:  
110/120 V; 130 V; 220/230 V; 240/250 V  
Frequency: 50/60 Hz.

Total power consumption:  
approximately 320 W.

### Fuses:

- a) Primary circuit
  - for 220/230 V or 240/250 V: 1.6 A slow blow.
  - for 110/120 V and 130 V: 3.15 A slow blow.
- b) Secondary circuit: 1.25 A slow blow.

The projector meets electrical safety requirements of VDE, Class 1. Interference suppressed (FN VDE 0875). This equipment conforms with the requirements of EEC Directive 76/889 with respect to radio interference.

## Control system

Push buttons for slide changing: forward (with additional possibility of manual slide selection) and reverse.

Zero-position indicator (LED) which lights when the slide tray is zeroed

Snap facility making numerous visual effects

12-pole standard socket (Figure C) with connections for dissolve units

### Socket connections:

$a_1 + a_4 = 24 \text{ V a.c.}$  (maximum load 750 mA rms).

$b_4 + a_5 = 20 \text{ V pulsed d.c.}$  (maximum load 750 mA rms).

$a_3 + a_4 = \text{external control.}$

$b_5 + b_6 = \text{slide tray zero reset.}$

$a_6 = \text{zero reset switch in gate}$   
(for zero reset signal).

$b_3 + b_4 = \text{forward slide change}$  (pulse duration 0.2 to 0.75 seconds with 50 Hz, and 0.18 to 0.65 seconds with 60 Hz).  
Slide changing is continuous with a continuous pulse.

$b_2 + b_4 = \text{reverse slide change}$  (pulse duration 0.3 to 0.85 seconds with 50 Hz, and 0.27 to 0.7 seconds with 60 Hz).  
With activated snap change pulse duration 0.7 to 0.8 seconds with 50 Hz, and 0.6 to 0.7 seconds with 60 Hz).

$b_1 + b_4 = \text{snap change}$  (pulse duration  $\geq 0.18 \text{ sec.}$ )

6-pole DIN socket, Figure D, to take CAROUSEL Remote Control, KODAK Interval Timer, KODAK S-AV Infrared Remote Control, Model TF, Slide Control Units, and Programmer.

Connections 2 + 3 = Forward slide change.

Connections 1 + 3 = Reverse slide change. (Pulse duration as for  $b_3 + b_4$  and  $b_2 + b_4$  of the 12-pole socket.)

For control purposes, connections 6 + 3 can supply approx. 20 V d.c. at a maximum current of 750 mA.

S-AV 2050 AF Projector:  
Automatic slide focusing using infrared radiation reflected by the slide; over-ride feature included. Autofocus on-off by switch (7).

**Wiring diagram of S-AV 2050 Projector**  
see page 52.

**Wiring diagram of S-AV 2050 AF**  
see page 53.

## Dimensions (Figure E)

Length: 262 mm

Width: 284 mm

Height: 101 mm

Height with slide tray: 151 mm

Weight (without slide tray): approx. 7600 g.


Weight of slide tray: 540 g

Equipment subject to minor appearance changes.

KODAK, CAROUSEL and RETINAR are trade marks.

## KODAK CAROUSEL S-AV 2050 Projector

110 / 120 V	11-12	1-2	2-7	
130 V	11-12	1-2		6-7
220 / 230 V	12-1		2-7	
240 / 250 V	12-1			6-7



### Schaltplan

a = Netzschaltung  
 b = Netzschalter  
 c = Wärmeschutzschalter  
 d = Spannungswähler  
 e = Spaltpolmotor  
 f = Schalter für interne bzw. externe Lampenansteuerung  
 g = Gleichrichter  
 h = Diatransport vorwärts und freie Diawahl  
 i = Kupplungsmagnet  
 j = Sekundärsicherung  
 k = Schalter für Umschaltung auf Reservelampe  
 L<sub>1</sub> = Betriebslampe  
 L<sub>2</sub> = Reservelampe  
 m = Schalter für Tachystoskop  
 o = Diatransport rückwärts  
 p = Umschaltmagnet für Vorwärts-/Rückwärtstransport und Tachystoskop  
 q = Leuchtdiode für Nullstellung  
 r = Nullstellungsschalter im Fallschacht  
 s = Magazin-Nullstellungs-Schalter  
 t = Fokussiermotor  
 u = Fernbedienung vorwärts  
 v = Fernbedienung rückwärts  
 w = Fernbedienung Fokusierung  
 x = Autofocus ein/aus (nur S-AV 2050 AF)

### Wiring diagramm

a = Mains fuse  
 b = Mains switch  
 c = Thermal overload cut-out  
 d = Voltage selector  
 e = Shaded pole motor  
 f = Switch for internal or external lamp control  
 g = Rectifier  
 h = Forward slide change and select  
 i = Clutch solenoid  
 j = Secondary fuse  
 k = Switch for lamp changeover  
 L<sub>1</sub> = Lamp in circuit  
 L<sub>2</sub> = Spare lamp  
 m = Switch for snap change  
 o = Reserve slide change  
 p = Reserving solenoid for forward/reverse slide change and snap change  
 q = LED for zero position  
 r = Zero reset switch in slide gate  
 s = Slide tray zero position switch  
 t = Focusing motor  
 u = Remote control forward  
 v = Remote control reverse  
 w = Remote control focusing  
 x = Autofocus on/off (S-AV 2050 AF only)

### Plan de câblage


a = fusible  
 b = commutateur marche/arrêt  
 c = disjoncteur thermique  
 d = sélecteur de tension  
 e = moteur asynchrone  
 f = commutateur pour la commande interne et externe de la lampe  
 g = redresseur  
 h = marche avant et projection d'une vue sélectionnée  
 i = électro-aimant d'inversion de la marche  
 j = fusible secondaire  
 k = contacteur pour la commutation de la lampe de réserve  
 L<sub>1</sub> = lampe en service  
 L<sub>2</sub> = lampe de réserve  
 m = contacteur du tachystoscope  
 o = marche arrière  
 p = contacteur marche avant/marche arrière et tachystoscope  
 q = diode luminescente de l'indicateur de la position zéro  
 r = capteur de position 0 dans le couloir vertical  
 s = contacteur de retour à zéro du magasin  
 t = monteur de mise au point  
 u = commande à distance marche avant  
 v = commande à distance marche arrière  
 w = commande à distance mise au point  
 x = mise au point automatique marche/arrêt (S-AV 2050 AF uniquement)

### Esquema del cableado

a = Fusible de la red  
 b = Interruptor principal de encendido/apagado  
 c = Interruptor térmico de sobre-carga  
 d = Selector de voltaje  
 e = Motor asíncrono  
 f = Interruptor para el control interno o externo de la lámpara  
 g = Rectificador  
 h = Avance de la diapositiva y selección  
 i = Solenoide del embrague  
 j = Fusible secundario  
 k = Interruptor para el cambio de la lámpara  
 L<sub>1</sub> = Lámpara dentro del circuito  
 L<sub>2</sub> = Lámpara de repuesto  
 m = Interruptor del taquistoscopio  
 o = Retroceso de la diapositiva  
 p = Solenoide de inversión para cambio de marcha; avance/retroceso y obturación rápida  
 q = Indicador LED de posición cero  
 r = Interruptor de puesta a cero en la ventana de proyección  
 s = Interruptor de puesta a cero en la bandeja de diapositivas  
 t = Motor de enfoque  
 u = Avance por control remoto  
 v = Retroceso por control remoto  
 w = Enfoque por control remoto  
 x = Interruptor de enfoque automático (S-AV 2050 AF)

## KODAK CAROUSEL S-AV 2050 Projector

<b>110 / 120 V</b>	<b>11 - 12</b>	<b>1 - 2</b>	<b>2 - 7</b>	
<b>130 V</b>	<b>11 - 12</b>	<b>1 - 2</b>		<b>6 - 7</b>
<b>220 / 230 V</b>	<b>12 - 1</b>		<b>2 - 7</b>	
<b>240 / 250 V</b>	<b>12 - 1</b>			<b>6 - 7</b>



## Schaltplan

**a** = Netzsicherung  
**b** = Netzschalter  
**c** = Wärmeschutzschalter

## Wiring diagramm

a = Mains fuse  
b = Mains switch  
c = Thermal overload cut-out

## Plan de câblage



a = fusible  
b = commutateur marche/arrêt  
c = disjoncteur thermique

## **Esquema del cableado**

a = Fusible de la red  
b = Interruptor principal de encendido/apagado

## KODAK CAROUSEL S-AV 2050 AF Projector

110 / 120 V	11-12	1-2	2-7	6-7
130 V	11-12	1-2		
220 / 230 V	12-1		2-7	
240 / 250 V	12-1			6-7



### Schema elettrico

- a = fusibile
- b = interruttore
- c = interruttore termico di sicurezza
- d = selettore di tensione
- e = motore asincrono
- f = interruttore per comando lampada interno/esterno
- g = raddrizzatore
- h = interruttore per cambio dia-positiva in avanti e selezione delle diapositive
- i = solenoide
- j = fusibile secondario
- k = interruttore per commuta- zione sulla lampada di riserva
- L<sub>1</sub> = lampada di esercizio
- L<sub>2</sub> = lampada di riserva
- m = interruttore per l'otturatore rapido
- o = trasporto diapositiva in avanti
- p = solenoide per cambio dia- positiva avanti/indietro e comando otturatore rapido
- q = diodo ottico di azzeramento
- r = interruttore di azzeramento nel vano di caduta
- s = interruttore di azzeramento del caricatore
- t = motorino per la messa a fuoco
- u = comando a distanza in avanti
- v = comando a distanza all'in- dietro
- w = comando a distanza per la messa a fuoco
- x = interruttore dell'autofocus (solo nel modello S-AV 2050 AF)

### Schakelschema








- a = netzkering
- b = netschakelaar
- c = thermische beveiliging
- d = spanningskiezer
- e = kortsluitankermotor
- f = schakelaar voor in- of externe lampenschakeling
- g = gelijkrichter
- h = diatransport vooruit en keuze willekeurige dia
- i = koppelmagneet
- j = secundaire zekering
- k = schakelaar voor om- schakeling op reservelamp
- L<sub>1</sub> = in gebruik zijnde lamp
- L<sub>2</sub> = reservelamp
- m = schakelaar voor Tachysto- scoop
- o = diatransport achteruit
- p = schakelmagneet voor trans- port voor/achteruit en Tachystoscoop
- q = LED voor nulstand
- r = nulstelschakelaar in beeld- venster
- s = nulstelschakelaar magazijn
- t = scherpstelmotor
- u = afstandsbediening vooruit
- v = afstandsbediening achteruit
- w = afstandsbediening scherp- stelling
- x = autofocus aan/uit (alleen S-AV 2050 AF projector)

### Kopplingsschema

- a = Nätsäkring
- b = Huvudströmbrytare
- c = Termosäkring (överhett- ningsskydd)
- d = Spänningsskopplare
- e = Spaltmotor
- f = Brytare för intern resp. extern lampstyrning
- g = Likriktare
- h = Diatransport framåt och fritt diaval
- i = Kopplingsmagnet
- j = Sekundärsäkring
- k = Brytare för omställning till reservlampa
- L<sub>1</sub> = Driftslampa
- L<sub>2</sub> = Reservlampa
- m = Brytare för "snap-change"
- o = Diatransport bakåt
- p = Omkopplingsmagnet för matning framåt/bakåt och "snap-change"
- q = Lysdiod för nollställning
- r = Nollställningsbrytare i fall- schakt
- s = Nollställning av magasinet
- t = Skärpeinställningsmotor
- u = Fjärrkontroll framåt
- v = Fjärrkontroll bakåt
- w = Fjärrkontroll skärpeinställ- ning
- x = Autofokus (på/av)









### Kytinkakaavio

- a = pääsulake
- b = pääkytkin
- c = yllämpösuoja
- d = jännitteenvaaliointi
- e = suojaamaodotettu oikosulku- moottori
- f = lampun ohjauskytkin
- g = tasasuuntaaja
- h = dian siirte eteenpäin ja valinta
- i = kytkinsolenoidi
- j = toisiosulake
- k = lampunvaihtokytkin
- L<sub>1</sub> = lampun virtapiiri
- L<sub>2</sub> = varalämpö
- m = pikavaihokytkin
- o = suunnanvaihtosolen oidi dian siirrolle
- p = eteenpäin/taaksepäin ja pikavaisto
- q = nolla-asennon ilmaiseva LED
- r = kuvaportissa oleva nollaus- kytkin
- s = diakasetin nollauskytkin
- t = objektiivin tarkennusmoottori
- u = kauko-ohjaus eteenpäin
- v = kauko-ohjaus taaksepäin
- w = kauko-ohjaustarkennus
- x = automaattitarkennuksen kytkin (vain S-AV 2050 AF)

**A****B****C****D****E**

**ZUBEHÖR**  
**ACCESSORIES**  
**ACCESSIONS**  
**ACCESORIOS**

**ACCESSORI**  
**TOEBEHOREN**  
**TILLBEHÖR**  
**TARVIKKEET**



# KODAK RETINAR S-AV 1000 und S-AV 2000 Objektive

## KODAK RETINAR S-AV 1000 and S-AV 2000 Lenses

### KODAK RETINAR S-AV 1000 Lenses

		55 mm	85 mm	100 mm	150 mm*	180 mm*	75-120 mm
Vergütung Coating	Couche Revestimiento	●	●	●	●	●	●
24x36 cm	40x40 mm	[ ] + [ ]	[ ] + [ ]	[ ] + [ ]	[ ] + [ ]	[ ] + [ ]	[ ]
Länge Length	Longueur Longitud	125 mm	125 mm	125 mm	156 mm	190 mm	148 mm
Front-Ø Front tube Ø	Tube Ø devant Tubo delantero Ø	73 mm	73 mm	73 mm	63 mm	63 mm	61 mm
Gewicht Weight	Poids Peso	174 g	108 g	108 g	206 g	205 g	239 g
Lichtstärke Aperture	Aperture Abertura	f/2.8	f/2.8	f/2.8	f/3.5	f/3.5	f/3.5
Anzahl Linsen Elements	Elements Número de lentes	5	3	3	3	3	7
Bildwinkel Field angle	Champ Angulo de proyección	48°	36°	30°	32°	26°	32°-20°

### KODAK RETINAR S-AV 2000 Lenses

26 mm      36 mm      51 mm      70 mm      93 mm      135 mm\*      150 mm\*  
 (26.4 ± 0.3)    (35.4 ± 0.3)    (50.6 ± 0.5)    (72.5 ± 0.5)    (92.8 ± 0.5)    (134.4 ± 0.7)    (149.8 ± 0.7)

Vergütung Coating	Couche Revestimiento	MC	MC	MC	MC	MC	MC
24x36 cm	40x40 mm	[ ]	[ ]	[ ] + [ ]	[ ] + [ ]	[ ] + [ ]	[ ] + [ ]
Länge Length	Longueur Longitud	151 mm	125 mm	125 mm	127 mm	125 mm	125 mm
Front-Ø Front tube Ø	Tube Ø devant Tubo delantero Ø	73 mm	78 mm	78 mm	78 mm	78 mm	73 mm
Gewicht Weight	Poids Peso	721 g	457 g	389 g	386 g	320 g	437 g
Lichtstärke Aperture	Aperture Abertura	f/2.8	f/2.8	f/2.8	f/2.4	f/2.5	f/2.8
Anzahl Linsen Elements	Elements Número de lentes	9	7	6	5	5	5
Bildwinkel Field angle	Champ Angulo de proyección	77°	61°	56°	38,6°	33°	23°

200 mm\*\*      253 mm\*\*      45 mm PC      60 mm PC      93 mm PC      85-210 mm\*\*  
 (200.5 ± 1)    (252.5 ± 1)    (45.2 ± 0.5)    (59.8 ± 0.5)    (93.1 ± 0.5)    ZOOM

Vergütung Coating	Couche Revestimiento	MC	MC	MC	MC	MC	MC
24x36 cm	40x40 mm	[ ] + [ ]	[ ] + [ ]	[ ]	[ ]	[ ]	[ ]
Länge Length	Longueur Longitud	164 mm	214 mm	142 mm	138 mm	138 mm	176 mm
Front-Ø Front tube Ø	Tube Ø devant Tubo delantero Ø	73 mm	73 mm	72.5 mm	72.5 mm	72.5 mm	68 mm
Gewicht Weight	Poids Peso	618 g	870 g	447 g	359 g	389 g	769 g (1320 g)
Lichtstärke Aperture	Aperture Abertura	f/3.5	f/4	f/2.8	f/2.8	f/2.8	f/3.9
Anzahl Linsen Elements	Elements Número de lentes	5	5	6	6	5	15
Bildwinkel Field angle	Champ Angulo de proyección	16°	13°	50°	39°	26°	27°-12°

\* Für die Projektion von 40x40 mm Dias empfiehlt wird den Spezialkondensor (CAT 706 0833) einzusetzen.

\*\* Spezialkondensor grundsätzlich notwendig liegt dem Objektiv bei.

\* For projection of 40x40 mm slides the use of the special condenser lens (CAT 706 0833) is recommended.




\*\* Use of the special condenser lens necessary and enclosed with the lens.

\* Pour la projection de diapositives 40x40 mm il est recommandé d'utiliser un condenseur KODAK CAROUSEL (CAT 706 0833).


\*\* Il est nécessaire d'utiliser le condenseur fourni avec l'objectif.

\* Para la proyección de diapositivas de 40x40 mm se recomienda el uso de la lente condensadora especial (No. CAT 706 0833).

\*\* Es necesario el uso de la lente condensadora especial que se incluye con el objetivo.




M




KODAK S-AV  
Programmable Dissolve Control


N O














KODAK RETINAR S-AV1000 Lenses



KODAK VARIO-RETINAR  
S-AV 2000 Zoom Lenses 85-210 mm



KODAK RETINAR S-AV 2000 Lenses



# Projektionsbildbreiten

## Projected picture sizes

### Dimensions des vues projetées

### Anchura de la imagen proyectada

